# **OPERATING MANUAL**

CURRENT CONTROLLER OC 99

# **►** MULTISPAN

## **Technical Specification:**

- 1) Micro Controller Based.
- 2) Size: 27 X 76 X 116 mm
- 3) Supply: 230V AC ± 10%, 50Hz
- 4) Input: 0 To 30 Amp AC (Inbuilt CT).
- 5) Output: 1 Relay 1 C/O ,5 Amp at 230V AC
- 6) Knob for over current & under current setting
- 7) Din rail mounting.



M: Glows when power is on.

O/C: Glows when overloads

U/C : Glows when underloads (Dry run)

Reset Key (RST)

This key is used to manual reset the relay.

# NO C NC AMULTISPAN 17 OC 99 11 12 23 4 30 Over Current M O/C U/C Under Current 70 11/90% RST 50 71/25% L N

### **INITIAL DELAY TIME:**

Initial Delay time is fixed to 7 Sec. So, no action would take place during this period.

### **OVER CURRENT SETTING:**

Upper Knob is provided for set Current value range from 4 T0 30mA.


### **UNDER CURRENT SETTING:**


lower Knob is provided for set under current value range from 25 T0 90% of over current.

### **WORKING:**

- 1) When power turn ON, Relay will be initially ON. After seven Second, if current is in between over current & under current. The relay remains ON.
- 2) If current is outside band of over current & under current value. The relay remains off.
- 3) Press (RST) key the relay will be OFF after 7 Second. Check the current value if current is in between over current and under current Relay remains ON.

### **TERMINAL CONNECTION:**





Product improvement and upgrade is a constant procedure. So for more updated operating information and support, please contact our Helpline: 9978991474/75 or Email at marketing@multispanindia.com